

772 QUICK REFERENCE OPERATION AND MAINTENANCE GUIDE



MAINTENANCE SCHEDULE

DAILY

- Wash exterior surfaces of the machine with a mild detergent solution using paper towel, rinse with clean water and dry. The screen should only be cleaned using damp paper towel, NO water or fluids to be sprayed directly on the screen
- Remove drip tray, and wash in mild soap solution. Rinse with clean water and reinstall drip tray on unit

QUARTERLY (performed by qualified service engineer)

- Remove, wash, and dry air filter(s)
Reinstall when completed

YEARLY (performed by qualified service engineer)

- Rear seals for beater motors need to be inspected and serviced
- Sanitize the unit and syrup lines

WARNING LIGHTS STATUS		SOLUTIONS		
		CAUSE	LCD DISPLAY	SOLUTION
RED light flashing (any single barrel)	PRODUCT OUT • Lights flashing NOT READY • Any single barrel	Out of syrup	SYRUP OUT	Replace empty syrup (BIB) container
All RED lights flashing (all barrels)	PRODUCT OUT • Lights flashing NOT READY • All barrels	Out of CO ₂	CO ₂ OUT	Replace empty CO ₂ tank
RED light continuously ON (any barrel)	DEFROSTING • Lights flashing NOT READY • Any single barrel	Out of water (H ₂ O)	WATER OUT	Check water (H ₂ O) supply
	NOT READY • Light flashing Any single barrel	Unit defrosting	DEFROSTING	Select barrel then once window comes up select "OFF" Select barrel again then select "ON"
All RED lights ON and beaters not turning	NOT READY • Light flashing Beater not turning All barrels	Unit in first freeze after defrost	FREEZING	Wait until unit completes first freeze down cycle
RED light ON, beater is off and not turning	NOT READY • Light flashing Beater not turning Any single barrel	Unit is in "sleep" mode	SLEEPING	Select barrel then select "ON"
No lights and unit is not running	No lights and unit is not running	Barrel is turned off	OFF	
		Unit is not plugged in or breaker has been tripped	No message on display	Plug in unit or reset circuit breaker. Then restart unit

HOW TO REFILL BARRELS

- Follow the on-screen instructions. Use the arrows to navigate menu. Use check mark to make a selection.
- Use appropriate button to highlight the barrel to be refilled.
- Follow the on screen instructions and press the corresponding button below your choice.
- Press the corresponding button below your choice.

QUICK REFERENCE GUIDE FOR BAG IN BOX (BIB) REPLACEMENT

HOW TO CHANGE AN EMPTY BIB WITH COMPATIBLE CONNECTOR

- Unscrew connector **A** and remove empty box
- Place new BIB box on rack and open flap
NOTE: DO NOT use a sharp instrument to open flap
- Pull bag connector **B** from box and remove dust cap
- Rinse connector **A** in warm water
- Screw connector **A** to connector **B**
- Resume operation

FOR TECHNICAL SERVICE CALL 0800 011 4010