

14 - Error codes

ID	Description	Activate condition	Cease condition	Log
17	Leaking outlet valve (small leak)	2 refill cycles without dispensing within 5 minutes	Reset button	Y
18	Leaking outlet valve (large leak)	2 refill cycles without dispensing within 1 minutes	Reset button	Y
19	Refilling boiler takes too long	Inlet valve open for > 2 minutes	Reset button	Y
21	Boiler water heating is defective	Heating was continuously on for > 11 minutes	Reset button	Y
25	Water temp. sensor defective	Temp. < 5 °C OR Temp. > 120 °C	Automatically when reading within limits	Y
27	Drip tray full	Drip tray full	Automatically	Y
30	Cooling box temperature too high for too long (liquid milk /chocolate concentrate in machine)	> 10 °C more than 12 hours	Reset button	Y
31	Cooling box temperature too low for too long	<-1 °C more than 12 hours	Reset button	Y
32	Cooling box sensor defect	Temp. < -5 °C OR Temp. > 60 °C	Automatically when reading within limits	Y
60	Mixing tray not in place	Microswitch open	Microswitch closed	Y
71	Flushing overdue	Flushing one day overdue	Flushing executed	Y
73	Cleaning overdue	Cleaning one day overdue	Cleaning executed	Y
102	Recipe not found	Recipe not found	Reset button	Y
201	Heater output fault	Open/short circuit	Reset button	Y
202	Air breaker valve fault	Short circuit	Reset button	Y
203	Instant valve fault	Open/short circuit	Reset button	Y
204	Instant fan fault	Open/short circuit	Reset button	Y
205	Spare valve 1 output fault	Open/short circuit	Reset button	Y
206	Spare valve 2 output fault	Open/short circuit	Reset button	Y
207	Spare valve fault	Open/short circuit	Reset button	Y
208	Left BiB valve fault	Open/short circuit	Reset button	Y
209	Right BiB valve fault	Open/short circuit	Reset button	Y
210	Left air valve fault	Open/short circuit	Reset button	Y
211	Right air valve fault	Open/short circuit	Reset button	Y
212	Left air pump fault	Open/short circuit	Reset button	Y
213	Right air pump fault	Open/short circuit	Reset button	Y
214	Hot water valve fault	Open/short circuit	Reset button	Y
215	Cooler fan fault	Open/short circuit	Reset button	Y
216	Peltier output fault	Open/short circuit	Reset button	Y
217	Inlet valve fault	Open/short circuit	Reset button	Y
218	Concentrate motor fault	Open circuit	Reset button	Y
219	Gear pump fault	Open circuit	Reset button	Y
220	Mixer motor fault	Open circuit	Reset button	Y
240	Configuration fault	Recipe and configuration do not match	Reset button	Y
241	Boiler overtemp	Boiler above overtemp limit	Automatically	Y
242	Schedule error Cleaning/flushing	Cleaning/flushing schedule error	Reset button	Y
243	Water treatment panel removed	Microswitch open	Microswitch closed	Y
244	Pump blocked	>99.9% PWM and flow < 4.0 for 1.5s	Reset button	Y
245	Button stuck	Button pushed for too long	Check buttons	Y
246	Water filling too long	>1 minute water still not filled in tank	Reset button	Y