



# 563 Series Drink Quality Reference Guide




**1 Check the syrup BIB**  
If syrup box is empty, then replace BIB. Make sure BIB connector is properly plugged in. DO NOT touch any keys. Machine will restart automatically.



**2 Check for CO2**  
If ALL BARRELS are not working, check CO2 tank. Replace if empty. DO NOT touch any keys. Machine will restart automatically.



**3 Check for water**  
If ALL BARRELS are not working, check water shut-off. If you do not have water at fountain, you may have a water problem. DO NOT touch any keys. Machine will restart



**4 Check for power**  
If ALL BARRELS are not working, and no lights are displayed on front door, check to ensure unit is plugged in. If it is plugged in, check circuit breaker.

If the above steps do not resolve the issue, continue to Step 5



**5 Check for liquid level**  
Defrost the barrel and verify the barrels are filled to the correct levels. Follow steps a through d below to defrost each barrel individually and determine if the liquid levels are correct.

**a**

Press OFF then DEFROST to defrost the barrel in question




**b**




**b**


**b**



**c**



**d**



Press RUN to refreeze

RUN